

# IPPT

INDUSTRIAL PROCESS PRODUCTS & TECHNOLOGY

IPPT.CA / APRIL 2022

VOLUME 34 / ISSUE 2



## **AIM FOR LONGEVITY FOR YOUR BLENDING EQUIPMENT**

**PLUS**

**FOCUS ON:**  
MIXING & BLENDING

**ALSO:**  
How Rising Gas Prices,  
Corporate CSRs are  
Driving the Transition  
to Electric Boilers





## PROCESS NEWS

### 5 Can Canada's mining and mineral sector step in for Apple?

As the West steps up sanctions against Russia, raw metals integral for electronics and semiconductors are needed from new sources.

#### FOCUS: MIXING/BLENDING COVER STORY

### 6 5-Minute Blending Going on Four Decades

Since their installation in 1983, this plastic engineering company's mixers have rarely been idle. Over the last 12 years, one mixer has had 34 hours of downtime and the other just 4.5 hours.

### 11 Laser Marking Automation Goes Beyond Robotics

### 14 How to Select Proper Diaphragm Materials

#### FOCUS: TEMPERATURE

### 16 RISING GAS PRICES, CORPORATE SOCIAL RESPONSIBILITY DRIVE TRANSITION TO ELECTRIC

As gas prices climb, companies are adopting economical, zero emission electric steam and hot water boilers and are fulfilling high-priority environmental Corporate Social Responsibility (CSR) initiatives.

## DEPARTMENTS

- 4 Editorial
- 8-10, 19 Products
- 20 CPCA Corner
- 20 Coming Events
- 22 Advertiser Index

COVER IMAGE: NORDRODEN / ISTOCK / GETTY IMAGES PLUS

ISSN 0836-737X. IPP&T is published 6 times per year by Annex Business Media. Canada Post Publications Mail Agreement No. 40065710. Return undeliverable Canadian addresses to: Circulation Department, 111 Gordon Baker Rd., Suite 400, Toronto, ON M2H 3R1. No part of the editorial content in this publication may be reprinted without the publisher's written permission. © 2022 Annex Business Media. All rights reserved. Opinions expressed in this magazine are not necessarily those of the editor or publisher. No liability is assumed for errors or omissions. All advertising is subject to the publisher's approval. Such approval does not imply any endorsement of the products or services advertised. Publisher reserves the right to refuse advertising that does not meet the standards of this publication. Printed in Canada.

IPP&T's series of eBooks are digital magazines focusing on a single area of process measurement and controls. The eBooks are designed to provide information and solutions to help you improve your industrial processing operations.

#### eBooks planned for 2022

- » March - Calibration
- » May - Gas Detection & Analytics
- » September - Powder/Bulk Solids Handling
- » October - Sensors



To ensure you receive your copy of the downloadable eBook, sign up to IPP&T's eNewsletter at [www.ippt.ca](http://www.ippt.ca)





One of two Munson Rotary Batch Mixers, model 700-TSC-180-MS, installed at PLENCO in 1983.

# FIVE-MINUTE BLENDING GOING ON FOUR DECADES

Since their installation in 1983, this plastic engineering company's mixers have rarely been idle.

The Plastics Engineering Company (PLENCO) manufactures a wide range of custom-formulated molding compounds and industrial resins, and a big share of its production is dedicated to novolac and resol thermoset molding compounds

— also known as phenolic resins — which it sells under the PLENCO trademark.

These resins are highly adaptable and used across many applications. As a result, the company tailors its products to each customer's requirements. That could entail adjusting the molecular weight, moisture content, viscosity, pH, particle size, reactivity and other properties.

Immediately prior to packaging, the resins are blended with reinforcements, minerals, fillers and/or liquid additives, a task performed by two model 700-TSC-180-MS Rotary Batch Mixers which have been in service since 1983.

## Five-minute tumbling prevents degradation

The mixers have no agitators, internal shafts or related bearings or seals. Instead, a horizontally oriented vessel rotates on external trunnion rings located at each end. Ingredients flow into the vessel through a stationary inlet at one end and

*"We get a good thorough blend but we don't degrade the product. If we used a typical paddle mixer, we would grind the granules against each other and create dust."*



Continuous rotation of the drum during discharge prevents stratification of ingredients having disparate sizes, shapes and bulk densities, and empties the batch in a steady stream.

discharge through a stationary outlet at the other. Within the vessel are mixing flights, also called baffles or lifters, which create a gentle four-way tumble-turn-cut-fold



The hinged access doors at either side of the vessel provide access to all material contact surfaces for cleaning and visual inspection.





**These Munson Rotary Batch Mixers have been in near-constant use since 1983. Records for the last 12 years show that one mixer has had 34 hours of downtime and the other just 4.5 hours.**

mixing action that produces on-spec blends in three-to-five minutes.

Randy Block, a mechanical engineer at Plastics Engineering, says, "We get a good, thorough blend without degrading the product."

To fill the vessels, a pneumatic conveyor transports resins from compounding units to a holding hopper, which also separates out dust. When enough material accumulates in the hopper, it is discharged to one of the mixers as it slowly rotates.

After the mixer receives a dose of powdered additives from a loss-of-weight hopper above, a valve stops the flow and the mixer makes a preset number of revolutions. When called for, liquid additions are pumped through spray nozzles onto a wide bed of moving material within the mixing vessel. At the end of the batch cycle, the mixer's discharge gate opens while the vessel is still rotating. This allows the mixing baffles to guide the batch toward and through the discharge gate with little or no residual.

"They do a good job of moving the material quickly and efficiently," Block says. "If we've got a straight dry material, there isn't much to clean out."

The gentle mixing action is critical, Block says, because it preserves product quality.

"We get a good thorough blend but we don't degrade the product. If we used a typical paddle mixer, we would grind the granules against each other and create dust. That doesn't happen with the Munson blender."

Continuous rotation of the drum during discharge prevents stratification of ingredients having disparate sizes, shapes and bulk densities, and empties the batch rapidly in a steady stream.

"That's important because it minimizes wait times at the packing stations," Block says. "Because of



that quick discharge, we are more efficient when packing bulk containers.

"We've made the same product as

a 5,000 lb (2,268 kg) order and as a 250,000 lb (113,398 kg) order," Block says. "And blending is just as uniform on short runs as it is across larger ones," Block says.

The mixing flights also create a dynamic bed of material, ideal for incorporating liquid additions.

"We get a good consistent dispersion. The product doesn't get too wet in some parts and less wet in other parts," Block says. "A typical paddle mixer would give us a less even coating."

Since their installation in 1983,

the mixers have rarely been idle. Over the last 12 years, one mixer has had 34 hours of downtime and the other just 4.5 hours.

"The longevity of the machines is a testament to my predecessors, who selected them," says Block. "We've been pleased with the lack of downtime and maintenance costs. They're quality pieces of equipment and just plain reliable." IPPT

[www.munsonmachinery.com](http://www.munsonmachinery.com)

**Plastics Engineering Company**

[www.plenco.com](http://www.plenco.com)



## Because Calibration is a matter of Confidence

**AMETEK**  
SENSORS, TEST & CALIBRATION

AMETEK Sensors, Test & Calibration (STC) is one of the world's leading manufacturers and developers of calibration instruments for temperature, pressure and process signals serving a wide range of industries!



Contact us today for more information:

1.888.863.8010 | [www.cameroninstruments.com](http://www.cameroninstruments.com)  
[info@cameroninstruments.com](mailto:info@cameroninstruments.com)

