

# CHP *Packer*

INTERNATIONAL  
Cosmetics | Healthcare | Household | Pharmaceuticals

*update*

May 2025 Vol. 32 No. 3

A Binsted Publication



**PATIENT-FRIENDLY  
PACKAGING  
LAUNCHED BY  
SANNER**

# ROTARY BATCH MIXER SLASHES CYCLE TIMES

EW Packaging contract manufactures and packages powder, tablet and capsule products, protein powders, energy drink mixes, and sports nutrition products. Customers include national warehouse clubs and dietary supplement retailers.

Founded in 2001 as EW Trading dba EW Packaging, CEO Rob Lonas renamed it EW Packaging when he brought the company's packaging and printing services in house. Today EW operates six blister-filling lines and four bottle-filling lines and uses flexographic printers to customise pouch and blister foils. It also machines its own tooling, which shortens turnaround times and reduces costs.

In 2016, the company began blending dietary supplement and food powders and manufacturing tablets and capsules, but the company's V-cone blender proved inefficient. "The machine was a lot of work and there was a lot of downtime," Lonas says. "It took at least 30 minutes to get a load in and out, plus another 15 to 20 minutes of actual mixing."

Next, he tried a ribbon blender, which reduced loading and unloading times but compromised blend quality. "The ribbon blender has corners, dead zones, where the powder isn't mixed," he says. Sometimes EW added as much as 10 percent more active ingredient to the products than required for HPLC testing to confirm that the product met the label claim. In addition, the ribbon blender's impeller put product quality at risk, Lonas says. "It's chops up

the ingredients and damages the product at the same time."

## **G**entler, more accurate blending

To improve EW's blending operation, Lonas purchased a 425 L (15 cu ft) Munson Rotary Batch Mixer that loads, blends, and discharges in about 15 minutes - half the time of the previous blenders. The unit's horizontal vessel rotates on external trunnion rings located at each end, handling ingredients gently because it has no agitators. Instead, the vessel has internal flights that create a four-way tumble-turn-cut-fold mixing action, producing homogenous blends without generating heat, shear or stratification. Lacking internal shafts, the mixer has no seals that are in contact with the product.

*"The Rotary Batch Mixer gives us a perfect HPLC test every time"*

- Rob Lonas  
Chief Executive Officer  
EW Packaging

To initiate a blending cycle, operators hand-weigh ingredients into a drum. A plant-based protein product may contain up to eight ingredients, while a flavoured creatine product may contain up to four. The drum containing the weighed batch is then lifted onto a mezzanine and dumped through a security screen into a hopper that discharges into the mixer's stationary inlet. A collection hood contains fugitive dust during the loading process, while a single

external seal prevents the escape of dust during vessel rotation.

Lonas highlights the Rotary Batch Mixer's gentle mixing action in his business conversations. "It's part of my sales pitch for whatever the job is - encapsulation, tableting or just blending a powder," he says. "This mixer just folds in the ingredients. It's not smashing them or pounding them together."

Blends are discharged from the mixer through a stationary outlet. Batches destined for encapsulation or tableting flow into mobile hoppers that are rolled into the adjacent room for those processes. Powder products are discharged into a screw conveyor that transports the batch to the feed hopper of an auger filling machine, which dispenses it by weight into bottles, canisters, tubs, or most any container.

The vessel leaves almost no residue following discharge. "There aren't any corners or pockets that can collect powder," Lonas says. Between blending campaigns and when switching products, operators wash, rinse, and swab-test the vessel interior in accordance with Good Manufacturing Practices.

Lonas says that the blends are always on-spec, and overages range between 2 percent and 3 percent instead of 10 percent previously. "I sold my V-blender and my ribbon blender. The Rotary Batch Mixer gives us a perfect HPLC test every time."

## **S**mall size, big output

Despite its modest volumetric capacity, the mixer outputs high volumes because it loads and discharges quickly and blend times



are short, as little as 3 to 6 minutes, Lonas says. "When we started getting bigger orders, we got nervous at first thinking our mixer wasn't big enough, but we ran some big orders with no problems." In one case, EW Packaging blended some 80 batches of a protein powder over four days, filling all of it into 2.3 kg (5 lb) tubs.

"The future for us is growing the powder business because we have our powder lines so dialed in. It's

a profitable and a fast way to fill bottles." The company's fastest line fills as many as 50,000 bottles a day, which includes capping, induction sealing, metal detecting, checkweighing, labelling, lot coding, and neck banding.

"We seldom tell customers 'No' unless they come in with a liquid," Lonas says. "If we don't have the right machinery, we buy it. Our niche is getting new products going for people and cranking it out,

getting them into the market fast. We get a lot of business because of our blister capabilities and because we can do short-run stuff. There aren't many other places on the West Coast that can do that."

Lonas calls the mixer his workhorse. "I think we changed a seal once. There's not much maintenance to do on it. It's one of our most reliable machines."

✉ [info@munsonmachinery.com](mailto:info@munsonmachinery.com)

## HANDLING COSMETIC AMPOULES SAFELY

A new sprayer with integrated ampoule breaker from Lutz Packaging provides protection against injuries. Sharp edges and unsafe handling – breaking glass ampoules is a challenge for many cosmetics users. Lutz Packaging from Wertheim has reacted by launching a new compact spray system with integrated ampoule breaker that makes for easier handling of the glass containers, thereby promoting consumer acceptance.

The new Easy Multiple Sprayer from Lutz Packaging combines two components: a removable spray head and a plastic housing containing an integrated ampoule breaker. It is extremely easy to use: the user inserts the ampoule into the housing from below and moves the glass container in any direction to break the ampoule head. With a twist, the ampoule head falls directly into a waste bin – without contact to skin and thus without risking injury. The user then inserts the opened ampoule into a rubber grommet, places it in the housing and screws on the spray head. After these few steps, the sprayer is ready for use immediately.

"Our solution will help cosmetics manufacturers to promote the acceptance of glass containers amongst consumers. We have not seen any comparable system on the market that offers both a spray function and also serves as ampoule breaker," says Wenke Hermanns, Business Development Manager at Lutz Packaging.